



## Checklist

1. Use special tools, avoid using excessive force
2. Only work on electrical components when the ignition is off
3. Route ignition cables such that they are not under tension
4. Pay attention to the correct and corresponding spark plug, cables and coils terminals.
5. Ensure orderly work, good contacts and exact positioning (e.g. of pencil coils)
6. In general: Refer to manufacturer's instructions and tightening torques
7. Always remove pencil coils in a straight line, do not tilt

